



ST8956 Multi-Function Recorder

Users Guide

Preface

Congratulations

Congratulations on choosing the Stack ST8956 Multi-Function Recorder. This system will give you a wealth of information to enable you to obtain the maximum performance from your vehicle.

Purpose of this manual

This manual will help you install and use the Stack ST8956 Multi-Function Recorder. It explains how to set up and configure the system for your vehicle.

Related Products From Stack

If you need information about other Stack motor sport products, these can be obtained from Stack or from your local Stack dealer. Products available from Stack include:

- Intelligent Tachometers
- Auxiliary Gauges
- Analogue and Digital Sensors
- Data Logging Systems
- Display and Logging Systems
- Radio Telemetry Systems
- Display and Analysis Software
- Video Overlay Systems
- Solid-state Video Recorders
- Tyre Pressure Monitoring Systems

Stack ® is a registered trademark of Stack Limited.

Information in this publication is subject to change without notice and does not represent a commitment on the part of Stack Limited. No responsibility is accepted for error or omission.

Copyright © 2009 Stack Limited

Contents

Chapter 1. Introducing the Multi-Function Recorder	1
How to use this Manual	2
Chapter 2. Getting Started	3
The Multi-Function Recorder Module	4
Main Wiring Harness	4
Network Wiring Harness	4
Connecting the Components	5
Chapter 3. Installing the Multi-Function Recorder	7
Who can install the Multi-Function Recorder?	7
Tools needed	7
Fitting the Multi-Function Recorder Module	7
Switches	8
Alarm/Recording Light	9
Shift Lights (optional)	9
Single Shift Light	10
ST539 Multi-Stage Shift Light Module	10
Engine Speed (RPM) Measurement	11
Wheel speed and transmission sensors	12
Fluid Pressure Sensors	15
Fluid Temperature Sensors	15
Exhaust Gas Temperature Sensors (EGT)	16
Position Sensors	16
ST749 Hydraulic Pressure Sensors	18
ST8996 CAN ECU Interface	19
Lap Timing System	20
Wiring harness	23
Chapter 4. ST8995-2 Display Module	25
Installing the Display Module	25
Peak Values (Tell Tales)	25
Alarms	26
Chapter 5. Using the Multi-Function Recorder	28
Configuring the system	28
Checks and Alarms	29

Lap times	29
Recording Data (Data Logging)	29
Calibrating Sensors	30
Chapter 6. System Specifications	31
Appendix A. Main Wiring Harness	33
Appendix B. Switch Functions	34
Appendix C. Light Functions	34
Appendix D. Service and Support	35
Stack Web-site	35
Contacting your Dealer	35
Service Enquiries	36
Stack Contact Details	39
Index	40

Chapter 1. Introducing the Multi-Function Recorder

The Stack ST8956 Multi-Function Recorder (MFR) can monitor a range of values, known as performance parameters, needed for effective car and driver management in most competitive situations.

The system consists of a ten-input sensor module with a built-in 32 megabyte data recorder.

All of the sensors may be recorded at rates up to 200 samples per second (200 Hz). Data recording can be configured to start when a parameter, eg, Engine Speed, rises above a preset value.

The recorder can hold thirty Runs and those runs can be downloaded to your PC using the Stack DataPro software (see separate Users Guide).

The MFR can be used to drive a configurable remote Display Module (ST8995-2) in real-time.

ST8956 Multi-Function Recorder can record up to 45 channels across the Stack CAN network as a whole, with a network capacity of up to 4000 sps.

A WiFi/WLAN data download option is available on the ST8956-W version of the MFR (please refer to the WiFi Addendum).

How to use this Manual

Stack recommends that you unpack and connect the components in the system **before** you install it in your vehicle. This will enable you to familiarise yourself with operating the system and configuring it for the vehicle in which you intend to install it.

This manual starts by taking you through the process of checking the system before installation, installing it in your vehicle, configuring the system and finally using it.

- ! *This manual does not attempt to explain how to interpret or use the information from the ST8956 Multi-Function Recorder as this is very specific to the type of vehicle in which it is installed and the type of competition in which that vehicle is engaged.*

Chapter 2. Getting Started

This chapter guides you through the initial unpacking and setting-up of the equipment for pre-installation checks and familiarisation with its operation.

Standard Multi-Function Recorder Items

The ST8956 Multi-Function Recorder is supplied with the following standard components:

Quantity	Description
1	Multi-Function Recorder Module (ST8956)
1	Sensor Harness (ST875-202)
1	ECU Engine Speed Extender (ST918024-101)
1	Network Starter Harness (ST877)
1	Stand-alone Power Lead (ST918078)
1	CAN-USB Network Interface (ST8990)
1	Recording Switch (ST517)
3	Internal G sensors
1	DataPro Software (ST920033)
1	DataPro Quick-start Guide (ST542095)
1	Designer Quick-start Guide (ST542068)

Optional Items

1 or	Multi-Stage Gear Shift Warning Light (ST539) Single Gear Shift Warning Light (ST534 or ST537) and (ST918081) adapter cable
1	Infra-red Lap Timing Kit (ST546)
1 1 1 2	ST8995-2 Display Module including:- Display Harness Extender (ST918094) Alarm Light (ST536) Peak & Lap Switches (ST510)
1	CAN ECU Interface Option (ST8996)
Various	Sensors to suit your needs
Various	Harness Extenders to suit those sensors

The Multi-Function Recorder Module

The Multi-Function Recorder Module consists of a compact cast aluminium module. That module is connected to up to ten external sensors by a wiring harness with a 19-way military connector. A second wiring harness with a 4-way military connector is used to connect power to the module and for downloading data to a PC.

Main Wiring Harness

Each of the wires in this harness is labelled:-

Label	Connection to
AL	Recording or Alarm light
SL	Gear shift light
S1, S2 and S3	Peak, Recording/Layer & Lap Switches
LAP	Optional Lap timing sensor
PA1	Engine speed (RPM) or 5 volt sensor
PA2 to PA4	Pulse or 5 volt sensors
A5 to A10	5 volt sensors


Network Wiring Harness

Each of the wires in this harness is labelled:-

Label	Connection to
B+	Battery positive (9 – 18 volts)
B-	Battery negative (Earth)
unlabelled	CAN-USB connection to PC

Connecting the Components

Refer to the diagram below which shows the wiring for the Multi-Function Recorder:-



1. Connect the Sensor Harness to the Multi-Function Recorder Module.
2. Connect the three switches to the wires labelled S1, S2 and S3.
3. Connect the Recording/Alarm Light to the wire labelled AL.
4. Connect the optional Multi-stage Shift Light or Single Shift Light to the wire labelled SL.
5. Connect the optional CAN ECU adaptor harness to A5 and A6.

6. If you have the optional ST8995-2 Display Module, connect it to the wire labelled DSP.



Analogue inputs A9 and A10 MUST remain disconnected if a Display Module is being used.

7. Connect each of the sensors that you have purchased to the appropriate wire in the wiring harness. The first four sensor connections (PA1 to PA4) can handle either Pulse or Analogue (5 volt) sensors. The remaining six connections (A5 to A10) can only handle Analogue sensors.
8. Connect a 12v DC power supply to the power input cable, eg, from a car battery. B+ is battery positive and B- is battery negative. Protect the B+ line with a 5 amp fuse.
9. Switch on the 12v DC power supply.

You can now proceed to familiarise yourself with operating the Multi-Function Recorder.

Chapter 3. Installing the Multi-Function Recorder

This chapter guides you through installing the system in your vehicle.

Who can install the Multi-Function Recorder?

The Multi-Function Recorder can be installed by anyone competent in fitting electrical and mechanical accessories to cars.

Tools needed

No special tools other than normal workshop tools are required.

Fitting the Multi-Function Recorder Module

The Multi-Function Recorder Module should be fitted to a rigid part of the chassis which is not prone to movement or vibration caused by the engine or suspension. There should be ample space around the module to allow access for installation and maintenance.

Ensure that there is sufficient space near the connectors to allow the sensor wiring harness to be connected to the 19-way connector without any tight bends to the wiring near the connector.

In order to get the most accurate results from the internal G sensors, the Multi-Function Recorder Module should be aligned so that it is as close as possible to the three main axes (X, Y and Z) of the vehicle. The DataPro Designer Calibration function allows any minor out-of-axis errors to be corrected but it cannot be used to correct alignment errors of more than five degrees.

Switches

The three switches are used to control the operation of the Multi-Function Recorder.

The normal functions of the switches are either:

Switch	No Display Functions
1	<i>No action so need not be fitted</i>
2	Toggle recording on or off
3	Manual Lap Marker

or

Switch	Display Functions
1	Show Peak Values
2	Clear Alarms or Change Display Layer
3	Manual Lap Marker
1 & 2	Display Stack software version banner
1 & 3	Reset lap times and reset peak values

You can install the switches in any convenient location. When installing the switches, you should take account of the following considerations:

- The cable for each switch is approximately 400 mm (16") in length from the 19-way military connector so use extender cables if necessary.
- If using the optional Display, it is important that the driver can reach the Peak and Layer Switches easily in order to show peak values and to clear alarms. These switches would normally be fitted on or near the steering wheel.
- If the driver is also going to enter lap markers manually, the Lap Switch should ideally be fitted on the steering wheel.
- Drill a 13 mm (0.5") in a suitable panel or manufacture a bracket with a hole in it.

- Insert each switch from the reverse side of the panel and screw on the rubber cover from the front. Do not over-tighten the nut; just greater than hand-tight should be enough.

Alarm/Recording Light

The Multi-Function Recorder Module has a light which, depending on the configuration, does one of two things. If there is a Display present, it illuminates when an alarm is in force. If there is no display, it indicates that data is being recorded, ie, data logging is in progress, and flashes when the car passes a lap beacon.

The alarm light should be installed in a position so that it is visible to the driver when seated in the car.

- Drill a 13 mm (0.5") in a suitable panel or manufacture a bracket with a hole in it.
- Pass the light through the hole from the viewing side.
- Thread the plastic nut over the two wires and tighten it on to the light. Do not over-tighten the nut; just greater than hand-tight should be enough.
- Connect the wires to the RL cable on the sensor harness using an extension cable if necessary.

! *If you are using your own warning light, ensure that the bulb rating does not exceed 2 Watts otherwise the Multi-Function Recorder Module will be damaged.*

Shift Lights (optional)

The Multi-Function Recorder Module has the ability to illuminate a light to indicate it is time to change up a gear. The gear shift light comes on when the engine RPM exceeds a predefined values.

Two types of gear shift lights may be fitted as described below.

Single Shift Light

The Single Shift Light which, when illuminated, indicates that it is time to change up a gear.

The light should be installed in a position so that it is visible to the driver while seated in the car.

- Drill a 13 mm (0.5") in a suitable panel or manufacture a bracket with a hole in it.
- Pass the light through the hole from the viewing side.
- Thread the plastic nut over the two wires and tighten it on to the light. Do not over-tighten the nut; just greater than hand-tight should be enough.
- Connect the wires to the SL cable on the sensor harness using the adapter harness supplied with the light.

! *If you are using your own light, ensure that the bulb rating does not exceed 2 Watts otherwise the Multi-Function Recorder Module will be damaged.*

ST539 Multi-Stage Shift Light Module

This module contains five high-intensity LEDs which illuminate in turn as the engine RPM increases. The set-points for each LED are configured using DataPro Designer (see separate User Guide).

- Site the Multi-Stage Shift Light Module in front of the driver so that the LEDs can be seen while seated in the car.
- Mount it using the Dual Lock™ tape supplied or use the M3 tapped holes (10 mm maximum depth) in the body of the Shift Light Module.
- If you wish to take advantage of the night-time illumination level, mount the push-button Dimmer Switch within easy reach of the driver. Pressing that switch toggles between pre-set high and low brightness levels.

- Identify the ‘SL’ wire on the Sensor Harness. Connect the mini sure-seal connector on the shift light harness to this wire.

Engine Speed (RPM) Measurement

The engine speed (RPM) is measured by connecting the engine speed wire directly to the ignition system. A single wire from the connector labelled PA1 connects the Multi-Function Recorder to the ignition system.

- ! *The PA1 input has special properties which will reject noisy signals making it ideal for connecting to engine speed signals, particularly signals obtained from magnetos. For this reason Engine speed signals should not be connected to PA2 to PA4.*

Connecting the Multi-Function Recorder to the ignition system

The Multi-Function Recorder can be connected to engines with a variety of ignition systems as shown in the table below:

Ignition System	Connection Point
ECU	Direct to tachometer output
Coil and Points	Use adapter (ST493) to connect to the coil negative (low tension) terminal

The following connections are shown in greater detail:

- Electronic ignition or ECU connection
- Contact breaker system

Electronic Ignition or ECU Connection


Connect the PA1 wire directly to the “Tacho” output of the electronic ignition or Engine Control Unit.

The signal can be either a 5 volt or 12 volt square wave..

Contact breaker system

Connect the PA1 wire to the negative terminal on the coil using a ST493 ESPD Interface cable.

- ! *Do not connect the PA1 cable directly to the coil or the Multi-Function Recorder Module will be damaged.*



- ! *Ensure the ignition system wire is held away from the ST493 wiring for greater than 100 mm (4 inches).*

Wheel speed and transmission sensors

The Multi-Function Recorder can be connected to a range of proximity sensors to measure, for instance, wheel or transmission speeds. These sensors are used to measure wheel or shaft rotation in order to display the speed in MPH/km/h or RPM. The sensor provides an electrical pulse to the system each time a ferrous object, such as a CV joint bolt, passes near to the end of the sensor. When configuring the system you need to supply the number of ferrous objects that will be counted for each revolution. In addition for speed you must supply the circumference of the wheel using DataPro Designer's Calibration facility.


Fitting proximity sensors

These sensors are triggered by a number of 'Targets' (see *Sensor Targets*). It is essential that these devices and their cables are positioned as far as possible from all sources of

intense heat and from the ignition HT leads to avoid interference.


Sensor targets

The targets can be any suitable metallic object which passes within range of the sensor tip. Iron and mild steel targets are preferred as they give the strongest signal to the sensor. Aluminium, brass and copper targets give approximately one third of the sensing range which makes setting up the sensor difficult and may cause the speed signal to be unreliable.



It is important that the sensor and targets are rigidly mounted so they do not move with vibration. The sensor bracket should have a suitable hole for the threaded portion of the sensor to pass through. Targets should be at least 10 mm (5/8") across and stand 4 mm (5/32") proud (Fig.1). Smaller targets can be used but these will reduce the range. Small aluminium, brass or copper targets will generally not work.

Nothing except the targets should come within 6 mm (1/4") of the end of the sensor. If the sensor mounting position is to be recessed, a hollow of 24 mm (15/16") diameter and at least 4 mm (5/32") deep should be allowed around the sensor.



Sensor fitting and adjustment

1. Connect the Mini Sure-Seal connector of the proximity sensor to the system via PA1 to PA4 of the Sensor Harness. Turn on the power.
2. Assemble the first (rear) nut onto the sensor.
3. Insert the sensor into the mounting bracket hole and fit the front nut.
4. Rotate the wheel or shaft and move the sensor slowly forward by undoing the rear nut counter-clockwise until the built-in light (LED) comes on for every target. That light is used to check that both the mechanical and electrical installations have been performed correctly. This light should be ON when a target is in front of the sensor.
5. Undo the rear nut half a turn more.
6. Without rotating the sensor or rear nut, finger-tighten the front nut.
7. Tighten the rear nut with a 13 mm AF spanner. Do NOT let the sensor rotate.



Do not over-tighten; one flat of the nut should be sufficient. A small amount of silicone sealer will prevent it vibrating loose.

Checks for correct installation and adjustment

- Rotate the wheel or shaft and check that the built-in sensor light comes on for each target and goes off between each target.
- Check that both the sensor and targets are rigidly mounted.
- Check that the front nut or any fixings do not cover any part of the sensing end.



Check the gap between sensor and any of the targets is NOT less than 0.5 mm (3/16") so there is no risk of the sensor hitting the targets.

Fluid Pressure Sensors

The Multi-Function Recorder can be connected to a range of fluid pressure sensors to measure, for instance, Oil Pressure and Fuel Pressure.



Fitting the pressure sensors

- Position the sensors and their cables as far as possible from all sources of intense heat and from the ignition HT leads.
- Each sensor can either be screwed in directly to the monitoring point or fitted separately by using a suitable pressure hose to connect it to the monitoring point.
- Do not over-tighten the sensor.
- Plug the sensor's Mini Sure-Seal connector into any of PA1 to PA4 and A5 to A10 of the Sensor Harness.

Fluid Temperature Sensors

The Multi-Function Recorder can be connected to a range of temperature sensors to measure, for instance, Water Temperature and Oil Temperature.



Fitting the temperature sensors

- Position the sensors and their cables as far as possible from sources of intense heat and from the ignition HT leads.
- Mount each temperature sensor directly in the appropriate fluid line. Screw the sensor into a suitable mounting boss so that its tip lies near the middle of the flow of fluid.

- Plug the sensor's Mini Sure-Seal connector into any of PA1 to PA4 and A5 to A10 of the Sensor Harness.

Exhaust Gas Temperature Sensors (EGT)

The Multi-Function Recorder can be connected to a range of K-Type thermocouple sensors to measure, for instance, Exhaust Gas Temperature. These typically measure temperatures from zero up to 200°C (400°F) or 1100°C (2000°F).


Position Sensors

The Multi-Function Recorder can be connected to a range of position sensors for measuring throttle, steering or damper movements.

Plug the sensor's Mini Sure-Seal connectors into any of PA1 to PA4 and A5 to A10 of the Sensor Harness.

ST978 Rotary throttle position sensor


This sensor is designed to be fitted to the end of throttle butterfly shaft. Universal mounting holes are provided to allow the sensor to be bolted on to most standard throttle bodies.



- ! *This sensor is not designed to take radial loads and must be carefully aligned with the centre line of the throttle shaft. Misalignment will shorten the life of the sensor.*

ST979 Rotary position sensor with arm


This sensor has a spring loaded lever which should be attached using a length of stranded wire to, for instance, a throttle pedal.



1. Find a mounting position which does not interfere with the drivers feet or operation of the controls.
2. Once the intended location for fixing is determined, drill 4.5 mm (3/16") holes to provide clearance for the supplied bolts
3. Bolt the sensor in place and connect it to the wiring harness
4. Using the length of cable supplied, pass the end of the cable through the hole in the lever arm and attach the other end to the side of the pedal lever.
5. Adjust the cable tension until the lever arm is just pulled away from its resting position. This adjustment should be checked regularly to remove any slack in the cable which may give rise to errors in throttle position.

ST972/976 Linear Displacement Sensors

The linear displacement sensor should be mounted between the vehicle's chassis and a suspension member. These sensors are available with various maximum displacements to suit different suspension systems.



1. Find mounting positions on the suspension members and the adjacent chassis.
2. Once the intended location for fixing is determined, drill 5 mm (3/16") holes and fit suitable bolts.
3. Attach the sensor body to the chassis and the extending arm to the suspension.
4. Connect the sensor cable to the wiring harness.

! *The spherical bearings at each end of the sensor are designed to absorb any bending forces on the sensor rod and should not be restricted in any way. Failure to do this will result in bending forces being applied which will cause the sensor to fail.*

! *The sensor will be damaged if it is allowed to extend or compress beyond its normal range of movements.*

ST749 Hydraulic Pressure Sensors

The Multi-Function Recorder can be connected to a range of hydraulic pressure sensors to measure, for instance, Brake Pressure.




Fitting the pressure sensor

! *Reliable braking performance is vital to the safe operation of your vehicle and only a competent mechanic should attempt to fit this sensor. Only high pressure brake line quality fittings should be used.*

- Position the sensor and its cable as far as possible from all sources of intense heat and from the ignition HT leads.
- The sensor has a Dash 3 female thread. Use a suitable adaptor to join it to a three-way connector block inserted into the brake line.
- Ensure the sensor is mounted at a low point with its opening upwards to allow trapped air to be removed during the brake bleeding process.

ST8996 CAN ECU Interface

The CAN ECU Interface is used to connect the Multi-Function Recorder to an Engine Control Unit. With this interface it is possible to get parameters directly from the ECU saving the time and effort of fitting separate sensors.



Connect the harness by following these guidelines.

- The CAN Adaptor Harness must be connected to both analogue inputs A5 and A6.
- The green and white wires must be connected to CAN Lo and CAN Hi respectively on the CAN output of the ECU.



It is common for the CAN Hi and CAN Lo connections to be identified incorrectly. If no signal can be seen, it may just need the green and white wires to be swapped.

- The CAN terminator should be installed only if there is no terminator within the ECU.



To determine if the terminator is required, measure the resistance between CAN Hi and CAN Lo. No resistance needs the terminator and a resistance of 120 Ohms requires no terminator.

- Finally configure the Multi-Function Recorder for the CAN ECU interface using DataPro Designer.


Lap Timing System

The Lap Timing system consists of two parts:-

- A Lap Timing Sensor (ST543) which is fitted to your vehicle and responds to a coded infra-red signal.
- A Trackside Beacon (ST544) which transmits an infra-red beam to activate the lap timing sensor.

ST543 Lap Timing Sensor

The lap timing sensor is actuated by an infra-red beacon positioned at the side of the track. The sensor is fixed to a rigid bracket mounted at a convenient position on the outside of the vehicle where it is able to detect the signals from the beacon.




- It is secured through a 18mm (0.7”) diameter hole by two nuts with M18 x 1mm threads.
- This sensor must be positioned horizontally and square to the axis of the vehicle.

- In order to detect the signals from the beacon it must be situated outside the vehicle.
- It should, if possible, be positioned so that other vehicles that are being overtaken (or are overtaking) at the moment your vehicle passes the beacon do not block the signal.

! *After detecting a signal from a beacon, the system does not recognise any further signals for a period of ten seconds. This is to prevent multiple lap times being recorded if there is more than one Stack beacon positioned along the pit wall.*

ST544 Trackside Infra-Red Lap Beacon

The trackside infra-red lap beacon works with the ST543 lap timing sensor to trigger the Multi-Function Recorder to record a lap time.



The housing has a threaded socket on its base for mounting to a standard photographic tripod. It should be located as follows:

- As near to the start-finish line as possible. A feature of DataPro allows the offset between the beacon and the start line to be adjusted.

- At the same height as the on-vehicle infra-red sensor.
- Level so that it emits a horizontal beam.
- It must be between 2 and 30 metres (6 to 100 ft) from the vehicle when the vehicle passes it.
- Avoid positioning it so that the sun is directly behind it when it is being used.
- Where the unit is to be used for lengthy periods in very hot or sunny conditions, it should be protected by shading it from direct sunlight.
- Do not allow water to be sprayed onto the transmitter lenses. During wet conditions fit a protective peak over the beacon.



To prevent distortion of the coded infra-red signal, do not cover the beacon with a plastic bag.

Power supply to trackside beacon

The trackside beacon operates from a 12 volt DC supply. A sealed lead-acid battery with a minimum rating of 2.5 Amp/hour is recommended. This will provide about 15 hours of operation.

The condition of the battery is indicated by the colour of the LED indicator on the front panel of the unit:

- | | |
|-----------|---|
| Green | The voltage is, at present, adequate for use |
| Red | The voltage is too low (replace or charge the battery). |
| No colour | The battery is exhausted or disconnected. |

Wiring harness

The Multi-Function Recorder Module and the sensors, switches and lights are connected together by means of the wiring harness and sensor extender cables supplied with the system or the sensors.

The wiring harness can be fitted after the Multi-Function Recorder Module and all the sensors and switches have been installed.

The sensor harnesses have short cables terminated with Mini Sure-Seal connectors. Likewise the sensors have short cables terminated with the mating connector. Since neither of those short cables is likely to be long enough to reach the sensors in their installed positions, you will need to bridge the gap using extender cables which are available from your dealer in a variety of lengths.

Fitting the wiring harness

When fitting the harness on the vehicle, you should observe the following:


- Start by attaching the sensor harness to the Multi-Function Recorder Module by connecting the 19-way military connector.
- First position the ends of all the wires at the locations of the sensors, lights and switches to which each is to be connected, but do not connect them yet.
- All wires should be as far as possible and not less than 75 mm (3 inches) from sources of heat and electrical noise such as exhaust pipes, ignition HT leads, distributor caps etc.
- When you pass any wire through a bulkhead or dashboard, fit a cable gland into the hole so that the edge of the hole cannot chafe the wire.

! *Particular care is needed when passing wires through holes in carbon fibre as the carbon can cut through cables very easily.*

- The download jack socket (the NET connector) should be mounted to the vehicle through a 25.4 mm (1”) diameter hole. It should be positioned so that it is easily accessible to the PC for downloading data when the vehicle comes into the pits. Packing washers are provided to ensure the socket is securely mounted.
- Connect the wires when all the sensors are in position and you have secured the wiring harness.

Mini Sure-Seal Connectors

The Multi-Function Recorder Module connects to its sensors via four way ITT Cannon Mini Sure-Seal (MSS) connectors. A plug (the smaller of the two connectors) can be found on the ends of the Sensor Harness and a receptacle on the cable from the sensor. The following polarity is observed in all cases:



! *Mini Sure seal connectors offer excellent vibration and waterproof performance. However they do not have a positive locking mechanism so must not be subject to bending or pulling load, as such loads can cause the connector to fail.*

Chapter 4. ST8995-2 Display Module

The ST8995-2 Display Module has been designed for presenting driver information in as clear and precise way possible.

Simple controls allow the display to be scrolled through six display layers by pressing the Layer Switch. Each layer can show either 2, 4, or 6 parameters.

During alarm conditions the whole display is used to present a warning message and its associated alarm value.

Installing the Display Module

The Display Module is fitted into a cut-out in the instrument panel/dashboard and secured using the two U-brackets at the rear. The dimensions for the cut-out are:

185 mm x 45 mm (7.3" x 1.8")

allow 35 mm (1.4") space behind the panel for clearance.

Connect the Display to the DSP connector on the Main Wiring Harness using the extender harness supplied.

! *Analogue inputs A9 and A10 MUST remain disconnected if a Display Module is being used.*

Peak Values (Tell Tales)

The Multi-Function Recorder System can display the peak values (sometimes called 'tell-tales') that have been recorded during a run for all the displayed parameters.

Peak values are updated only when the engine speed has exceeded its fixed 'gate value' of 3000 RPM *for at least one second* which allows the values to stabilise. Blipping the engine may not be enough to update the peak values. This is to prevent abnormal peak values from being recorded when, for example, the engine is either not running, is idling or is being warmed up.

Displaying the Peak Values

Press and hold the Peak Switch to show the peak values for the parameters currently being displayed. Release the switch to return to the normal display.

Resetting the Peak Values

You can reset all of the peak values manually. If the engine is running **at** or **above** its gate RPM when the peak values are reset, they are set to the current value of each performance parameter.

If the engine is running **below** its gate value, the peak values are not reset to the current values but are set to full-scale values appropriate for the type of peak which has been chosen.

To reset the peak values:

- Press and hold the Peak Switch to display the peak values.
- While holding that switch, press and hold the Lap Switch.
- With the Lap Switch held down, you will see the display revert to the current values. The new peak values that are stored are those being displayed when you release the Lap Switch.

Alarms

The Multi-Function Recorder when used with a display option has the ability to show warnings and alarms to alert the driver when certain parameters either exceed or fall below their alarm values. For example, a warning may be issued if the fuel pressure falls below its alarm value or if the oil temperature rises above its alarm value. You can adjust the alarm levels when you configure the Multi-Function Recorder using DataPro Designer.

You can configure the warnings so they are triggered only while another parameter is above or below a defined value,

eg, while the engine speed exceeds a certain RPM. Blipping the engine should not be enough to trigger a warning. This helps to prevent abnormal warnings from being triggered when, for example, the engine is either not running, is idling or is being warmed up.

Displaying an Alarm

When an alarm condition occurs, the built-in red warning light turns on.

Clearing an Alarm

Press the Layer Switch while an alarm is being displayed to clear that alarm.

Chapter 5. Using the Multi-Function Recorder

Configuring the system

Before using the Multi-Function Recorder it must be configured to work with the sensors and optional parts you have installed. This is performed using the DataPro Designer program.

There is no limit to the number of times configurations can be uploaded into the Multi-Function Recorder. So, as your system changes over time, perhaps by adding new sensors, changing the recording rates of existing sensors or modifying the layout of the optional ST8995-2 Display Module, new configurations can be created. This makes the Multi-Function Recorder a very powerful tool since it is so easy to adapt it to new environments.

Details of how to install the DataPro suite of software and how to use Designer to configure your Multi-Function Recorder is described in separate User Guides supplied with your system.

Configuration Memory

The uploaded configuration is stored in non-volatile memory so it is retained when the external power source is disconnected from the system.

If, after several years, the configuration (and any recorded data) is lost when the system is powered down, it is likely that the internal back-up battery will need replacing. In that case the Multi-Function Recorder Module should be returned to Stack for a service during which its internal battery will be changed.

! *Ideally the modules should be returned every 4-5 years to ensure no loss of data. An inspection fee will be charged.*

Checks and Alarms

You should check the system to ensure that all the sensors are detecting the correct values. This is accomplished using DataPro's Data Monitor (real-time display) function. You should run the engine up to its operational levels to check that the values displayed are accurate.

Lap times

Lap times are recorded whenever they are triggered by the optional infra-red lap timing system or when the driver presses the Lap Switch. When either of those situations occur, either the Recording Light will flash once or a lap time will pop up on the optional Display Module.

The lap times will be available to view in DataPro when the recorded data has been down-loaded to your PC.

Recording Data (Data Logging)

Recording can be set using DataPro Designer to start automatically when the Engine Speed exceeds a pre-defined RPM. The Multi-Function Recorder records channels at the rates chosen in Designer. When setting the recording rates Designer indicates the maximum amount of recording time which is possible with those rates.

If the optional ST8995-2 Display Module is not fitted, the Recording Light will illuminate while the system is recording. That light will go out when recording stops. If the Display Module is fitted, a message will pop-up on the LCD panel.

The ST8956 Multi-Function Recorder can record up to 30 runs of data. No more recording is allowed if the memory is full or the maximum number of runs is reached.

Once data has been recorded it can be downloaded to your PC using DataPro's Recorder features. Connect the Multi-Function Recorder to your PC using the Stack CAN-USB

interface cable. Connect it to the PC via the USB connector and to the Network Harness using the 4-way jack plug.

It is possible to put DataPro into download mode prior to the car being available, eg, before it arrives at the pits. Then all that is required to perform the download is to plug the jack into the on-vehicle socket. Data will be transferred to the PC immediately the connection is made.

! *For further details please refer to the Stack DataPro documentation.*

Calibrating Sensors

Certain sensors should be calibrated so that their recorded data is displayed correctly once downloaded to DataPro. The following parameters will need to be calibrated:

Parameter	Calibration
Wheel speed	Set the Wheel Circumference to the overall measurement of the sensing wheel
G sensors	Set the zero point for each G sensor with the race-ready vehicle standing on a level surface
Suspension sensors	Set the zero point for each suspension sensor with the race-ready vehicle standing on a level surface
Pedal positions: Throttle, Brake etc	Set the values for resting and fully depressed pedal positions
Steering position	Set the 90° left and 90° right steering wheel positions

! *For further details please refer to the Stack DataPro Designer documentation.*

Chapter 6. System Specifications

Power supply	9 to 18 Volts DC @ 0.3A typically 1 Amp max (fuse @ 5A)
Working temperature	-20 to +70 Degrees Celsius (-4 to 160 Degrees Fahrenheit)
Size	127 mm x 107 mm x 35 mm (5" x 4.22" x 1.38")
Weight	0.4 kg (0.9 LB)
Vibration	30 G, 50 to 2000 Hz, 1 Octave / min, 36 Hours
Humidity	0 to 100% condensing (Fully sealed)
Immersion	IP67

Analogue sensor inputs

Input Description	Value	Units & Notes
Input impedance	>1.0	Mohms (to +6.25v)
Input voltage measurement range	0 to +5.0	Volts min/max
Input over-voltage range	-2 to +18	Volts min/max
Input resolution	10bit (~5mV)	0-1023

Pulse sensor inputs

Input Description	Value	Units & Notes
Input pull-up	18	mA (to +6.25v)
Input edge threshold	5.5 ±0.5	Volts Note: Add 390R in series for 2.25v
Input over-voltage range	-2 to +18	Volts min/max
Max input frequency	2.5	KHz
High period pulse width	0.1	mS Min
Low period pulse width	0.1	mS Min

Pulse sensor outputs (S5V)

Output Description	Value	Units & Notes
Sensor 5v supply voltage	5.00 ±0.05	Volts
Sensor 5v supply current	100.0	mA max


Lap Marker inputs (LAP)

Description	Value	Units & Notes
l/p Impedance	5.0 \pm 0.5	kOhms (to +5v)
Negative edge threshold	2.5 \pm 0.5	Volts
Input over-voltage range	-2 to +18	Volts min/max
High period pulse width	5	mS Min
Low period pulse width	5	mS Min
Lap Marker blanking period	10	Seconds min

Battery power input (B+ & B-)

Description	Value	Units & Notes
Input voltage operating (B+ & B-)	9 to +18	Volts min/max
Input over-voltage range	-20 to +25	Volts min/max
Supply current	0.3 to 1.0	Amps typical – Max (fuse at 5A)

Appendix A. Main Wiring Harness



PA1 - PA4 & A5 - A10

- Pin 1 White
- Pin 2 Orange
- Pin 3 Red
- Pin 4 Screen

Appendix B. Switch Functions

No Display Functions	Switch
<i>No action so need not be fitted</i>	1
Toggle recording on or off	2
Manual Lap Marker	3

Display Functions	Switch
Show Peak Values	1
Clear Alarms or Change Display Layer	2
Manual Lap Marker	3
Display Stack software version banner	1 & 2
Reset lap times and reset peak values	1 & 3

Appendix C. Light Functions

No Display Functions	Light
Recording = illuminated	Recording light
Lap marker generated = flash	Recording light
Engine speed above shift set-point	Shift light

Display Functions	Light
Alarm active on display	Recording light
Engine speed above shift set-point	Shift light

Appendix D. Service and Support

At Stack we pride ourselves on having, not only a very high-quality engineered product range, we also strive to offer a first class service when it comes to supporting our customers and installed product base.

Stack Web-site

If you have a question about a Stack product or if you are experiencing a problem, we have made a wealth of information available on our web-sites where you can find the answers you need.

International
www.stackltd.com

United States
www.stackinc.com

Frequently Asked Questions

Log-on to the Stack web-site, click on **Motorsport Division** and then the **Support** tab at the top of the home page. Then click on the **FAQ Page** item.

If you need a User Guide click on the **Manuals and Download Support Area** item. You will be asked to submit some basic information for Stack's internal use but, once submitted, you will have immediate access to downloadable versions of our product manuals. These manuals will give clear instructions on the installation and correct operation of your Stack product as well as including useful Troubleshooting sections.

If you still have unanswered questions, please contact the Dealer from whom you purchased the product.

Contacting your Dealer

For a current list of dealers, log-on to the Stack web-site, click on **Motorsport Division** and then the **Where to buy** tab at the top of the home page and select the **Distributors** menu item.

When contacting your Dealer with a Technical Support or Service enquiry it is important that you have to hand the following information:

- Serial Number (found on the rear of the product).
- The Model Number.
- The date of purchase.
- A copy of the packing list supplied with the product.
- If it is a Data Logging product, please provide the TAG number, software licence number and DataPro version. Your Dealer will be able to advise you if you need help locating those numbers.

This information will help your Dealer ensure that your enquiry is handled and processed in an efficient manner.

Service Enquiries

If you or your Dealer have identified a fault with your Stack equipment, it is possible to return the goods for inspection. Your Dealer will help you with this. Before you return your equipment, please be aware that:

- All services and repairs are subject to an initial inspection. No commitment can be made to repair the goods in full or within a specified budget or timescale until this inspection has been completed.
- An initial inspection fee will be charged for all services. Payment will be required before we conduct the inspection. On completion of the inspection you will be advised of any work and costs involved in repairing the goods. At this point you will have the choice to proceed with or terminate this service.
- It is your responsibility to safely ship (at your expense) the goods to Stack. It is also your responsibility to arrange for the safe return of the goods, unless the goods have been repaired under warranty, in which case Stack will organise for the safe return of these goods. Please

ensure that the goods are adequately packaged and insured for the journey.

To arrange for your equipment to be returned for an initial inspection, please contact your dealer. The process for returning goods is as follows:

1. Contact the dealer from whom you purchased the goods.
2. Your dealer will complete and send you a Returns Authorisation form by fax or mail. This form includes a unique Returns Authorisation Number (RAN).
3. You must include that form with the goods when shipped. Your dealer will be able to advise you on the shipping of your goods.
4. At the time of shipping your goods you should arrange to make payment via your dealer for the initial inspection. Your dealer will advise you of this fee.

Your goods will then be returned to Stack's factory in the UK. The inspection and service process is explained below:

1. On receipt of your goods they will undergo the initial inspection by one of our engineers.
2. Our engineers will attempt to reproduce the fault as reported and an assessment will be made with regards the complexity of the corrective action:
 - i) If the corrective action can be identified at this stage, we will contact you with details of the repair work required, as well as a quotation for that work.
 - ii) If corrective action cannot be easily identified at this stage, a full diagnosis and a "Corrective Action Assessment" will be conducted. Using this information we can then contact you and advise on the next course of action and will quote on expected duration and cost of repairs where applicable.
3. Once we have received your authorisation to proceed with any repair work required, we will complete the work and request payment. A full final test will be conducted before the goods are packed ready for shipping.

4. Once we have confirmation that payment has been received for this service, the goods will be returned to you.

Cost and Duration of Service

All service and repair work is conducted at Stack's factory in the UK. Both the cost and the duration of the service will depend on:

- Your Geographical location.
- Whether the goods are covered by a warranty.
- The complexity of the repair work required once the initial inspection has been completed.

Cost and Duration of Inspection – Your dealer will be able to advise on the cost of the initial inspection work. As stated above it is your responsibility to arrange for the safe shipment of the goods.

The time required to complete any service or repair work is dependent on the outcome of the initial inspection. At the time of receiving your RAN form, we will provide an estimated delivery time, which is subject to the outcome of the initial inspection.

Priority Service – If you require your goods to be returned faster than the estimated delivery time, we can offer a priority service, for which there will be an extra charge. Again, the time required to complete any service or repair work is dependent on the outcome of the initial inspection. Wherever possible we will return the goods within our priority delivery times:

- **UK** - 2-3 working days
- **USA & Rest of World** - 7 working days

Cost and Duration of Service and Repair – On completion of the initial inspection, we will be able to quote the final cost and expected duration of the service and any repair work. We will contact you for authorisation to complete the work and request payment. If you choose not to proceed

with this work, we will return the goods to you as we received them and you will only be charged for the initial inspection and return freight.

Harnesses and Sensors – Where goods returned include harnesses and sensors we will provide an inspection of that equipment to assess the functionality. We are unable to repair harnesses or sensors that have been cut or become damaged due to use.

Note: a small number of our sensors can be serviced or repaired. Please discuss with your dealer who will advise you of which sensors are serviceable.

Loan/Replacement equipment – Stack operate a return to base service and repair policy. We do not offer an advance exchange or loan scheme.

Stack Contact Details

Contact	International	United States
Email:	sales@stackltd.com	sales@stackinc.com
Web:	www.stackltd.com	www.stackinc.com

Index

- alarm light, 9
- alarms, 27
- calibrating sensors, 31
- CAN-USB, wiring label, 4
- checks and alarms, 30
- clearing an alarm, 28
- configuration memory, 29
- configuring the system, 29
- contact breaker connection, 12
- contacting your dealer, 36
- data logging, 30
- EGT sensor, 16
- electronic ignition), 11
- engine control unit), 11
- engine speed (RPM), 11
- engine speed (RPM), label, 4
- exhaust gas temperature, 16
- fitting multi-function recorder
 - module, 7
- fluid pressure sensor, 15
- fluid temperature sensor, 16
- frequently asked questions, 36
- gate value, 26
- gear shift light, 9
- gear shift light, wiring label, 4
- hydraulic pressure sensor, 19
- installing the multi-function recorder, 7
- labels on wiring, 4
- lap times, 30
- lap timing sensor, 21
- lap timing sensor, wiring label, 4
- lap timing system, 20
- light functions, 35
- linear displacement sensor, 18
- main wiring harness, 4, 34
- multi-function recorder module, 4
- multi-stage shift light, 10
- network wiring harness, 4
- peak values, 26
- peak values, resetting, 27
- performance parameters, 1
- points connection, 12
- position sensor, 16
- power supply, 6
- power supply to trackside
 - beacon, 23
- proximity sensors, 12
- recording data, 30
- recording light, 9
- recording light, wiring label, 4
- resetting the peak values, 27
- RPM gate value, 26
- service and support, 36
- service enquiries, 37
- shift light, multi-stage, 10
- shift light, single, 10
- shift lights, 9
- single shift light, 10
- Stack contact details, 40
- Stack web-site, 36
- standard components, 3
- switch functions, 35
- switches, 8
- switches, wiring label, 4
- tell tales, 26
- throttle position sensor, 17
- tools needed, 7
- trackside infra-red lap beacon, 22
- transmission sensors, 12
- unpacking, 3
- wheel speed sensors, 12
- wires in the harness, labels, 4
- wiring harness, installation, 24